

Technical Manual



01.007.01

**REMOVE AND INSTALL
SPOILER ASSEMBLY**

STARK FUTURE



SAFETY WARNINGS

Observe your local health and safety guidelines. Ensure a safe working environment. Wear appropriate protective gear. Deviating from the prescribed order may result in injury or damage to the products.



TOOLS

- TRX 30
- TRX 45



OPERATION TIME

8 Minutes

REMOVAL



WARNING

Before proceeding with any work on the bike, make sure it is turned off and the charger disconnected.

- 1 Unscrew the front spoiler bolts, 2x on each side.
- 2 Unscrew the seat rear center bolt.
- 3 Unscrew the side panel bolts, 1x on each side.
- 4 Grab the side panels and pull outwards to unclip it.
- 5 Pull the complete spoiler assembly backward and upward.

INSTALLATION



WARNING

Before proceeding with any work on the bike, make sure it is turned off and the charger disconnected.



NOTE

Check that the spoiler assembly fittings on the bike are clear of wirings or debris.

- 1 Slide the spoiler assembly forward and downward.
- 2 If necessary, press down and forward on the seat to align the rear center holes.
- 3 Tighten the spoiler assembly bolts.
 - 3.1 Tighten the rear center bolt to **8 Nm**.
 - 3.2 Tighten the side bolts to **20 Nm**.
 - 3.3 Tighten the front bolts to **5 Nm**.

starkfuture.com

ENG 2024-08

Copyright © 2023 Stark Future SL. All rights reserved.
Reproduction, even in part, as well as copying of all kinds,
is permitted only with the express written permission
of the copyright owner.

STARK FUTURE