

Technical Manual



05.015.01

**REMOVE AND INSTALL
FOOT PEG**

STARK FUTURE



SAFETY WARNINGS

Observe your local health and safety guidelines. Ensure a safe working environment. Wear appropriate protective gear. Deviating from the prescribed order may result in injury or damage to the products.



TOOLS

TRX 45



CONSUMABLES

- Lithium grease
- Medium strength thread locker



OPERATION TIME

5 Minutes

REMOVAL



WARNING

Before proceeding with any work on the bike, make sure it is turned off and the charger disconnected.

- 1 Unscrew the foot peg pin.
- 2 Hold the foot peg.



NOTE

Exercise caution when handling the foot peg sharp teeth.

- 3 Remove the foot peg pin.



NOTE

Carefully wiggle the foot peg to help slide the pin out.

INSTALLATION



WARNING

Before proceeding with any work on the bike, make sure it is turned off and the charger disconnected.

- 1 Clean the foot peg pin from any debris.
- 2 Apply grease to the smooth surface of the pin and medium strength thread locker to the thread.
- 3 Press the foot peg in place with the spring sitting in the right position and hold it.



NOTE

Exercise caution when handling the foot peg sharp teeth.

- 4 Insert the foot peg pin.



NOTE

Carefully wiggle the foot peg to help slide the pin all the way through.

5 Tighten foot peg pin to **20 Nm**.

starkfuture.com

ENG 2023-06

Copyright © 2023 Stark Future SL. All rights reserved.
Reproduction, even in part, as well as copying of all kinds,
is permitted only with the express written permission
of the copyright owner.

STARK FUTURE